
REVISIONS							
REV.	DESCRIPTION	DATE	SIGNATURE				
Α		2024-04-11	PB				



- 1. Remove Electroplating from edges of flange and threaded area where weld will be applied.
- 2. Center and position the DB Gland Flat to the plate.
- 3. Tack weld on the front side of the flange in four positions.
- 4. Continue welding around the flange until complete.
- 5. Complete a full seal weld on rear side of opening.

Ritad Drawn	Kontr. Check.	Granskad Reviewed	Godkänd	Арргоv.	Tolerans där ej annat anges Tolerance unless othervise not stated.	Smst. nr. Assembly drawing no.	Ersätter Replaces Ersattav	E Vikt	
РВ	РВ	OF	ML		Ytjämnhet där ej annat anges. Surface finish othervise not stated.	Material	Replaced of  Alla mått och uppgifter avser färdi annat anges	Weight	
240320	240411	240412	2404	12			All measures and other information refer to finished products unless othervise not stated.		
			7	INSTALLATION DRAWING FOR WELDED		Kund ordernr. Customer order no			
			<b>⊾</b> ®	DB GLAND		Ritn. nr. Draw. no.	Rev.		
BR	$\Delta T$	<b>TBE</b>	R	$\mathbf{J}$			1240122	2 A	